

BatteryShip.com

UP5530 Sony Clie PEG-UX50 Battery Installation Instructions

PLEASE NOTE: Patience and care, along with moderate technical and hand tool ability, are required for the successful replacement of a PDA battery. **Excessive force may result in damage to your PDA.** The instructions below come with no warranty, guarantee, proper, or improper assembly or use. The instructions below come with no warranty or guarantee. By utilizing these instructions, you agree to hold BatteryShip.com blameless and unaccountable for any and all damages, problems, or personal injuries that may or may not arise by your use of these instructions. Replacing your Clie battery may void any warranty you have on your PDA. **Please read all instructions and back up your data BEFORE replacing the battery.** If your Clie is a different model, use these instructions as a reference and consult your owner's manual or a technician if necessary.

Make sure your PDA is off and your hold switch is activated.

Remove the four screws on the back of the PDA using the included Phillips or mini flathead screwdriver (the mini flathead should work on the 5-pointed star screws if they are used). They will be located near the four corners of the device.

Once the screws have been removed, open the back Clie case upward. The case will remain attached at the top. Use the included plastic flathead screwdriver or any small flathead screwdriver to help open the case if needed.

Make sure that you are grounded before coming into contact with the PDA's internal parts.

Note the location and orientation of the original battery, battery connector, and connector wires within the device. You will see where the battery connects to the motherboard socket. Disconnect the old battery at the connector by **CAREFULLY** pulling outward on the connector with your thumb and forefinger or tweezers. Be very sure that you are pulling outward on only the part of the connector that comes out, **NOT** on the entire socket or on the wires themselves.

Remove the original battery from the battery compartment, using the plastic flathead to assist if needed. Be very careful not to bend or break the battery as you remove it.

Making sure that your new battery is facing the right direction, connect the new battery by pressing the connector at the end of the battery wires into the socket. Note the location of the prongs in the socket of the Clie and the location of the plugs for the prongs on the battery connector, and connect them accordingly. Do not press too hard or try to force the pieces together. They will fit easily when correctly aligned. Place the battery in its seat in the front case.

Press the back cover of the PDA on over the new battery and screw the four screws back in. **FULLY CHARGE** your new battery before use. Allow at least three hours.

PLEASE NOTE: Our tools fit the majority of Clie's, but some devices may have different screws installed for various reasons. If our tools do not fit your device, you may have the appropriate tool in a tool kit you already own. You can also check your local hardware or electronics store if you do not have the right tool at home.